


Bullet 6S

ORIGINALITY DESIGN SMART - AND BEAUTIFUL

.....



QUICK GUIDE



Consult the checklist below for all components.




Bullet 6S



Power adapter




Screw package



Manual



Screwdriver




Power	DC12±10%
-------	----------

Status light	<ul style="list-style-type: none"> • Solid red light on (3s~5s): network is malfunctional • Blinking red light: wait for network connection (slow) connecting the network (fast) • Solid blue light on: the camera is working correctly
--------------	--

Microphone	Capture sound for your video
------------	------------------------------

SD card slot	Support local SD Card storage (Max.128G)
--------------	--

Reset	Press and hold for 5 seconds to reset the camera (if you have modified settings, they will return to factory defaults)
-------	--



- 1 Fix the Camera to the wall with screws
- 2 Adjust camera angle to a correct view (as shown in the picture)

Download

CloudEdge is available for both iOS and Android OS. Search the name 'CloudEdge' in App Store or Google Play, or scan the QR-Code to download the App.

Support



ipad



iOS



Android



Download App(iOS&android)

Add device

Log in the CloudEdge, select "Add Device", and add the smart camera to the App according to the screen tips(Make the smart camera close to the router when configuring).



NOTE: If you need to re-select the WiFi network, please press and hold the "RESET" button for 5 seconds, the device will restart, and the indicator will be flashing red.

Q: The device cannot be previewed properly?

A: Check whether the network is normal, you can place the camera close to the router, and if not, it is recommended to reset the device and add it again.

Q: Why is it still in the list of devices after resetting?

A: The reset device only resets the network configuration of the camera, but cannot change the configuration on the App, remove the camera, and must be deleted by the App.

Q: How to cut the camera network to another router?

A: First remove and reset the device on the App and then configure the device again by the App.

Q: Why doesn't the device identify the SD card?

A: It is recommended to plug in SD card after power cut. Confirm whether the SD card is normally available and the format is FAT32. And the TF card can't be identified when the internet environment is not good.

Q: Why I can't get the notifications with my cell phone App?

A: Please confirm that the App has been running on the phone, and the relevant reminder function has been opened; Message notification and authority confirmation in the mobile phone system have been opened.

Video flip

Flip your video stream up or down for maximum flexibility.

Motion detection

Built-in motion sensors detect movement, and the camera will send you push notifications and app alerts.

Record

Support 24H continuous recording with high capacity SD storage.

Day & Night

Never miss a moment, even in complete darkness, with powerful night-vision technology.



Daytime



Night